

Compression Jointing

- 1.** Ensure that the pipe is cut square and that all burrs are removed.



- 2.** Remove threaded nut, washer and seal from the fitting.



- 3.** Place the threaded nut first onto the pipe, then the washer. Finally push the seal onto the pipe with the seal facing into the fitting.



- 4.** Insert the pipe into the fitting.



- 5.** Screw the threaded nut onto the body of the fitting. Once tight apply an additional $\frac{1}{4}$ turn.

